


ING  
R

From four-terminal  
to the receiver

Power supply

the emitter

Power supply



## Installation

The best place to  
make reconnection  
should be in a  
light in the room

Attention

Be careful of the  
distance between  
back

## T Emitter connecting

all distance to be no smaller than 2 meters. Install should  
indicularly to place, and is on-line at same level. Install  
off part again. When together at always line, receive the OFF  
fix, connect the line to install completion namely.

are big, so when shoot machine with receive the machine  
the phenomenon of the reaction, at this time should draw  
try. When install distance very near, discover not intelligent

ITING  
RINDOR

